

Manual wrap type portable toilet

# Wrappon PF-1

By the waste bag with thermocompression bonding and odor-sealing material, the excrement is individually sealed every time.



No smell

Easy operation

Secondary infection prevention

Space saving storable

Wrappon does not smell.



## Disaster toilet's big problems

From toilet garbage



Bad smell leaks and spreads.



Bacteria leak and become an infectious disease.



Problem Solved

By Wrappon Thermocompression confines bad smells and bacteria

The waste bag is made by the special odor-sealing material (BOS). The excrement is sealed and is individually Wapped by thermocompression. So, smell and bacteria are not leaking to outside. It leads to the prevention of secondary infections by not leaking bacteria to outside. This affordable portable toilet came to be able to do such as infectious disease and smell countermeasures. Live a safe and secure an evacuation life with this toilet !



Pour the special coagulant into toilet and excrete. It electifies and makes thermocompression to the waste bag to seal by pulling up the front lever.

※It's ok to pure the special coagulant after an excreation is over.

## What is the manual wrap type toilet, Wrappon PF-1 ?

Product name	Wrappon PF-1
Release date	April 5, 2022
Color	Navy
Rated voltage	Toilet seat unit : DC12~16V AC adapter : AC100V 50/60Hz
Rated consumption voltage	35W
Size	W376 × D510 × H400mm (assembled size)
	W170 × D560 × H410mm (size in the box)
Weight	5.0kg (in the box) / 4.2kg (product weight)
Materials	Main body / pedestal / toilet seat unit : Polypropylene Waste bag : polypropylene coagulant : High water absorption
Maximum load capacity	100kg



### Product features

#### Installed manual wrapping mechanism for sealed individual wrapping.

The manual wrapping mechanism does not use water. Seal the excrement each time by the thermocompression so it does not leak both smell and bacteria. It is very hygienic. And no need for the efforts of post-processing as the excrement(filth) is individually packed.

#### Easy assembly and operation

Assembly 1. Unfold the main body. 2. Insert the pedestal. 3. Install the toilet seat. Only three steps. After setting the waste bag, pull up the lever. By manual operation of lifting up, it turns electricity and give thermocompression bonding of the waste bag.

#### Light weight and compact

The total weight is approximately 5.0kg so the light weight makes it easy to move. The storage box size is 170mm(width) 560mm(depth) 410mm(length) so it does not take up storage space.

#### Can be used repeatedly

Because of plastic materials, the main body parts(main body, pedestal and toilet seat unit) are plastic so it can be used repeatedly.

**The first step to zero disaster-related death is to stock the toilet which is hygienic and can be used with confidence.**

**[Inquiry of the manual wrap type toilet Wrappon PF-1] is as follows.**



**NIHON SAFETY CO.,LTD.**  
**Wrappon division**

**e-mail : [wrappon@nihonsafety.com](mailto:wrappon@nihonsafety.com)**  
**w e b : <https://wrappon.com/english>**

Reception time 9:00~17:30 Please note that Sat.,Sun.,Holidays, New year holidays and for other reasons are holidays.